


Response to arbitrary loading (non-harmonic, non-periodic)

Impulse response



Impulse is mathematically represented by a Dirac-delta function

$$\delta(t-a) = 0 \quad \forall t \neq a$$

$$\int_{-\infty}^{\infty} \delta(t-a) dt = 1$$

Impulse load = $\hat{F} \delta(t-a) \bar{s}^T$

↓
unit of impulse

Impulsive response

The response of a system with zero initial condition due to an unit impulse acting at $t=0$ is called impulsive response and referred as $h(t)$

Eqn. of motion

$$m\ddot{u} + c\dot{u} + ku = \hat{F}\delta(t)$$

The effect of impulse acting at $t=0$ is equivalent to imparting an initial velocity $\frac{\hat{F}}{m}$

∴ The impulse response is equivalent to the free vibration response with initial condn $u(0)=0$ and $\dot{u}(0) = \frac{\hat{F}}{m}$

∴ The effect of applying an impulse load at $t=0$ is equivalent of giving an initial velocity $\dot{u}_0 = \frac{\hat{F}}{m}$.

Response of an under-damped SDOF system due to an impulse.

$$u(t) = e^{-\xi_3 \omega_n t} \left[u_0 \cos \omega_d t + \frac{\dot{u}_0 + \xi_3 \omega_n u_0}{\omega_d} \sin \omega_d t \right]$$


where, $u_0 = 0$ & $\dot{u}_0 = \frac{\hat{F}}{m}$

$$\Rightarrow \hat{u}(s) = \frac{1}{m\omega_d} e^{-\xi_3 \omega_n t} \sin \omega_d t$$

Response due to unit impulse load, $h(t) = \frac{1}{m\omega_d} e^{-\xi_3 \omega_n t} \sin \omega_d t$

$$h(t-\tau) = \frac{1}{m\omega_d} e^{-\xi_3 \omega_n (t-\tau)} \sin \omega_d (t-\tau)$$

Arbitrary loading



The shaded element of the force can be written as,

$$F(\tau) \Delta z \delta(t - \tau)$$

The response due to the shaded element of the load.

$$\bar{u}(t) = \frac{F(\tau) \Delta z}{m\omega d} e^{-\xi_3 \omega_n (t - \tau)} \sin \omega d (t - \tau)$$

$$= F(\tau) \Delta z h(t - \tau)$$

∴ The response due to the entire load,

$$u(t) = \sum_{\Delta z \rightarrow 0} F(\tau) \Delta z h(t - \tau)$$

$$= \int_0^t F(\tau) h(t - \tau) d\tau \rightarrow \text{Convolution integral / Duhamel integral}$$

Example Response of an under-damped SDOF due to step loading using convolution integral



$$u(t) = \int_0^t F(\tau) h(t - \tau) d\tau = \int_0^t \frac{P_0}{m\omega d} e^{-\xi_3 \omega_n (t - \tau)} \sin \omega d (t - \tau) d\tau$$

$$= \frac{P_0}{m\omega d} \int_0^t e^{-\xi_3 \omega_n (t - \tau)} \sin \omega d (t - \tau) d\tau = \frac{P_0}{m\omega d} I$$

$$I = \int_0^t e^{-\xi_3 \omega_n (t - \tau)} \sin \omega d (t - \tau) d\tau$$

$$= \left[\frac{1}{\omega d} e^{-\xi_3 \omega_n (t - \tau)} \cos \omega d (t - \tau) \right]_0^t - \int_0^t \xi_3 \omega_n e^{-\xi_3 \omega_n (t - \tau)} \frac{1}{\omega d} \cos \omega d (t - \tau) d\tau$$

$$= \left[\frac{1}{\omega d} - \frac{1}{\omega d} e^{-\xi_3 \omega_n t} \cos \omega d t \right] + \frac{\xi_3 \omega_n}{\omega d^2} e^{-\xi_3 \omega_n (t - \tau)} \sin \omega d (t - \tau) \Big|_0^t$$

$$- \int_0^t \frac{\xi_3^2 \omega_n^2}{\omega d^2} e^{-\xi_3 \omega_n (t - \tau)} \sin \omega d (t - \tau) d\tau.$$

